



HAWK
 Pompe MT-UV
 MT-UV pumps

H306UV
 H306UVR
 H306UVL

Item	Part Number	Description	Descrizione	Q.ty by Pump	H306UV	H306UVRL
1	0202.31	Crankcase	Carter	1		
2	0602.01	Plunger guide	Guida asta pistone	3		
*3	0001.03	Plunger oil seal	Anello radiale	3		
*4	0601.07	"O" Ring Ø1.78x31.47	"O" Ring Ø1.78x31.47	3		
*5	1201.04	Pressure ring 20mm	Pressore Ø20	3		
*6	0002.05	"V" seal, dia.20mm	Anello tenuta "V" Ø20	3		
*7	0300.09	Support ring 20mm	Diffusore Ø20	3		
*8	0300.56	Intermed. ring 20mm	Diffusore Intern. Ø20	3		
*9	0002.60	"U" seal, dia.20mm	Anello tenuta "U" Ø20	3		
*12	1601.17	Brass plug G3/8	Tappo G3/8	3		
*13	0603.06	Copper washer	Guarnizione rame	2		
*14	1602.04	Manifold housing	Testata	1		
*15	0601.19	"O" Ring Ø2.62x17.13	"O" Ring Ø2.62x17.13	6	◆	◆
*16	3604.70	Valve assembly	Valvola premontata	6		
*17	0601.65	"O" Ring Ø2.62x20.29	"O" Ring Ø2.62x20.29	6		
*18	1601.30	Valve plug	Tappo valvola	6		
19	1801.04	Manifold stud bolt	Vite M8x65	8		
20	1400.01	Washer	Rosetta Ø8.5	8		
21	1503.18	Valve seat	Sede valvola	6		
22	1202.00	Valve plate	Piattello valvola	6		
23	0900.30	Valve spring	Molla valvola	6		
24	0604.05	Valve cage	Gabbia valvola	6		
25	1400.02	Washer	Rosetta Ø6.4	8		
26	1802.07	Hexagonal screw	Vite M6x18	8		
27	0500.47	Bearing housing	Flangia	→	2	1
28	0500.48	Closed bearing housing	Flangia chiusa	1		◆
29	0601.63	"O" Ring Ø2.62x60,05	"O" Ring Ø2.62x60,05	2	◆	◆
30	0001.02	Crankshaft seal	Anello radiale	→	2	1
31	0200.06	Roller bearing	Cuscinetto a rulli	2	◆	◆
32	0004.07	Double-ended shaft	Albero doppia P.d.F.	1	◆	
33	0004.12	Single - ended shaft	Albero semplice P.d.F.	1		◆
34	0206.00	Crankshaft key	Chiavetta	1	◆	◆
35	1600.02	Oil dip stick	Tappo livello olio	1		
36	0301.02	Shim	Distanziale	1		
*37	1800.01	Plunger bolt	Vite pistone	3		
*38	1400.12	Copper spacer	Rosetta rame	3		
*39	0601.03	"O" Ring Ø1.78x7.66	"O" Ring Ø1.78x7.66	3		
*40	0009.04	Teflon ring	Anello antiestrusione	3		
*41	1200.10	Plunger 20mm	Pistone Ø20	3		
*42	1400.15	Copper spacer	Rosetta rame	3		
43	0003.01	Plunger rod	Asta pistone	3		
44	0100.01	Connecting rod	Biella completa	3	◆	◆
45	1502.01	Connecting rod pin	Spinotto	3		
46	1801.05	Connecting rod screw	Vite M6x25	6		
47	1500.01	Snap ring	Anello Ø10	6		
48	1401.02	Spring washer	Rosetta elastica Ø6	6		
49	0601.88	"O" Ring Ø2,62x126,67	Guarnizione coperchio	1		
50	0203.53	Crankcase cover	Coperchio	1		
51	0601.14	"O" Ring Ø1.78x14	"O" Ring Ø1.78x14	1		
52	0700.05	Sight glass, G3/4	Spia livello olio G3/4	1		
53	1801.12	Cover screw	Vite M6x16	4		

Item	Part Number	Description	Descrizione	Q.ty by Pump	H306UV	H306UVRL
54	0205.03	Shaft protector	Cappello protez.	1	◆	◆
55	1804.03	Shaft protector Screw	Vite Cappello	2		

		Part available in kit only	Particol. disponibile solo in kit
--	--	----------------------------	-----------------------------------

*		Part available in kit also	Particol. disponibile anche in kit
---	--	----------------------------	------------------------------------

SPARE PARTS KIT

Included Positions	Part Number & Description	Codice e Descrizione	Q.ty by Pump	H306UV	H306UVRL
4- 6 -7- 9	2608.09 Plunger Seals	2608.09 Guarnizioni pistone	1		
3- 4- 5- 6- 7- 8 9	2608.06 Complete Seals Packing 20mm	2608.06 Pacco completo Guarnizioni	3		
37- 38- 39- 40 41- 42	2608.02 Plunger	2608.02 Pistone	3		
15- 16- 17	2600.08 Complete Valve	2600.08 Valvola completa	6	◆	◆
3	2608.03 Plunger oil Seals	2608.03 Anelli tenuta olio Asta	1		
4- 5- 6- 7- 8- 9 12- 13- 14- 15 16- 17- 18	2608.07 Complete Manifold	2608.07 Testata Completa	1		